



Ozone Generator OZ60

Description

The ozone generator OZ60 is suitable for single-dose disinfection and odour elimination in rooms with mainly dry ambient conditions without the presence of persons.

The mobile OZ60 device can be used individually to eliminate odour-contaminated air or surfaces and for single-dose disinfection in small rooms.



OZ60 ozone generator

Functionality

The ozone is formed with the help of the device from oxygen in the ambient air and does not require any further additives.

The ozone molecules react quickly with a variety of organic and inorganic connections. This ensures that the "bad" air is odour-neutralised and disinfected in a perfect and reliable manner. The ozone produced is completely consumed by the oxidation process within a certain time and decomposes back into oxygen.

Applications

- Automotive preparation
- Pest control
- Odour elimination

Benefits

- Small design
- Handy stainless steel housing
- High-quality ozone components
- Assembly/maintenance ready to plug in
- Cable length 3m

Technical Data

Model	OZ60 12V	OZ60 230V
Dimensions (L x B x H)	248 x 165 x 107 mm	248 x 165 x 107
Housing material	Stainless steel V2A	Stainless steel V2A
Ozone components/ service life	Corona board/ 4000 h	Corona board/ 4000 h
Ozone performance	6000 mg/h	6000 mg/h
Power	40 W	70 W
Voltage	12 V DC	230 V ± 10% (50 – 60Hz)
Connection cable	3 m incl. Schuko plug	3m incl. Schuko plug
Weight	2.8 kg	2.8 kg
Protection class	IP 54	IP54
Fan power	90 m ³ /h	90m ³ /h