

# Ozone Generator OZ75

## Description

The ozone generator OZ75 is suitable for shock disinfection and odour elimination in large rooms **without people being present**.

The mobile OZ75 device is particularly suitable for the intermediate disinfection of air and surfaces even under humid ambient conditions.

## Functionality

UV light produces high-purity ozone without byproducts (NOx). The ozone molecules react quickly with a large number of organic/non-organic compounds, neutralizing odours and sterilizing the air thoroughly and reliably.

The ozone produced is usually completely consumed by this oxidation process over a certain time and decays back to oxygen.



OZ75 Ozone generator

## Applications

- Clinic/Hospital
- Pharmaceutical industrie
- Food industry
- Pest control

## Benefits

- Kompakte design
- Easy to handle stainless steel housing
- High-quality ozone components
- Assembly/maintenance ready to plug in
- Cable length 3m

## Technical Data

Model	OZ75
Dimensions (L x W x H)	570 × 255 × 250 mm
Housing material	Stainless steel V2A
Ozone components / service life	4 x UV emitters ozone high efficiency / 10.000 h
Ozone lperformance mg/h	7500
Power	100 W
Voltage	230V ± 10% (50 – 60Hz)
Connection cable	3 m incl. Schuko plug
Weight	9.0 kg
Protection class	IP54
Fan power	360 m <sup>3</sup> /h