

Ozone Generator OZ75

Description

The ozone generator OZ75 is suitable for shock disinfection and odour elimination in large rooms without people being present.

The mobile OZ75 device is particularly suitable for the intermediate disinfection of air and surfaces even under humid ambient conditions.

Functionality

UV light produces high-purity ozone without byproducts (NOx). The ozone molecules react quickly with a large number of organic/non-organic compounds, neutralizing odours and sterilizing the air thoroughly and reliably.

The ozone produced is usually completely consumed by this oxidation process over a certain time and decays back to oxygen.



OZ75 Ozone generator

Applications

- Clinic/Hospital
- Pharmaceutical industrie
- Food industry
- Pest control

Benefits

- Kompakte design
- Easy to handle stainless steel housing
- High-quality ozone components
- Assembly/maintenance ready to plug in
- Cable length 3m

Technical Data

Dimensions (L x W x H)	570×255×250 mm
Housing material	Stainless steel V2A
Ozone components / service life	4 x UV emitters ozone high efficiency / 10.000 h
Ozone lperformance mg/h	7500
Power	100 W
Voltage	230V ± 10% (50 – 60Hz)
Connection cable	3 m incl. Schuko plug
Weight	9.0 kg
Protection class	IP54
Fan power	360 m³/h